




The Mobile Robot Company

Knowledge Center — Autonomous Operation · 2026-08-04

<https://info.mobilerobot.com/documentation/user-guides/autonomous-operation>

Autonomous Operation

In automatic mode the J1600 drives itself to [saved destinations](https://info.mobilerobot.com/documentation/user-guides/location-management/) (<https://info.mobilerobot.com/documentation/user-guides/location-management/>), avoids obstacles on the way, and delivers pallets at floor level. Autonomous work always starts with a person: [the operator creates the task, confirms the mode change, and can take over at any moment](https://info.mobilerobot.com/documentation/user-guides/operator-manual/) (<https://info.mobilerobot.com/documentation/user-guides/operator-manual/>).

Starting an autonomous run

1. [Pick up the pallet manually](https://info.mobilerobot.com/applications/scenarios/manual-pickup-and-autonomous-delivery/) (<https://info.mobilerobot.com/applications/scenarios/manual-pickup-and-autonomous-delivery/>) and select or create a task on the touchscreen — see [Task Management](https://info.mobilerobot.com/documentation/user-guides/task-management/) (<https://info.mobilerobot.com/documentation/user-guides/task-management/>).
2. Execute the task. The robot asks to [enter automatic mode](https://info.mobilerobot.com/support/troubleshooting/robot-will-not-enter-autonomous-mode/) (<https://info.mobilerobot.com/support/troubleshooting/robot-will-not-enter-autonomous-mode/>).
3. Confirm with the physical LED start/resume button. The [key switch](https://info.mobilerobot.com/safety-compliance/safety-functions/mode-selection/) (<https://info.mobilerobot.com/safety-compliance/safety-functions/mode-selection/>) must be in the automatic position.
4. Step clear when the interface instructs you to. The robot moves only after confirmation.

While the robot drives

- [Top speed](https://info.mobilerobot.com/products/j1600/dimensions-and-performance/) (<https://info.mobilerobot.com/products/j1600/dimensions-and-performance/>) is 5.4 km/h (1.5 m/s / 3.4 mph).
- The robot localizes on the 3D map built during manual driving and plans its own route to the destination — no fixed paths, wires, or reflectors. See [Creating the First Map](https://info.mobilerobot.com/documentation/getting-started/creating-the-first-map/) (<https://info.mobilerobot.com/documentation/getting-started/creating-the-first-map/>).
- It [detects and avoids obstacles](https://info.mobilerobot.com/products/j1600/navigation-and-obstacle-avoidance/) (<https://info.mobilerobot.com/products/j1600/navigation-and-obstacle-avoidance/>) in dynamic environments, [routing around people and objects](https://info.mobilerobot.com/applications/scenarios/operation-in-crowded-environments/) (<https://info.mobilerobot.com/applications/scenarios/operation-in-crowded-environments/>).
- Preferred travel zones can be defined for safer routing through production areas.

- A 360-degree protective field, monitored by two 2D safety LiDARs and an independent safety controller, covers forward and reverse travel. The [field changes with speed](https://info.mobilerobot.com/safety-compliance/safety-functions/safety-field-adjustment/) and expands at higher speeds.
- Blue floor-light strips display the protected area and the vehicle's status.

[Person detection](https://info.mobilerobot.com/safety-compliance/safety-functions/person-detection/) and [braking](https://info.mobilerobot.com/safety-compliance/safety-functions/braking/) carry certified safety [Performance Levels](https://info.mobilerobot.com/safety-compliance/safety-functions/performance-levels/) — see [How J1600 safety works](https://info.mobilerobot.com/safety-compliance/safety-overview/how-j1600-safety-works/).

Delivery and after

The robot drops the pallet at floor level, then performs the post-delivery action from the task: [return to origin or operator](https://info.mobilerobot.com/applications/scenarios/deliver-and-return/), proceed to another point or parking, or [stop and wait](https://info.mobilerobot.com/applications/scenarios/deliver-and-wait/). With [Advanced software](https://info.mobilerobot.com/products/software/advanced-software/) it can also be called to a location ("[come to me](https://info.mobilerobot.com/applications/scenarios/come-to-me/)") via a mobile app or web interface, and it can drive itself to an automatic charger — see [Charging](https://info.mobilerobot.com/documentation/user-guides/charging/).

Operating limits in automatic mode

- [Level floors](https://info.mobilerobot.com/documentation/installation/floor-requirements/): only: automatic gradeability is 0° / 0%. Slopes and dock plates are manual work.
- [Indoor operation](https://info.mobilerobot.com/documentation/installation/operating-environment-requirements/): within 5–40 °C and 20–80% non-condensing humidity.
- Automatic delivery is floor-level only; higher drops are a manual capability.

Taking over

Manual control is immediately available at all times:

- grab or move the tiller to regain manual control;

- use any of the [three emergency-stop buttons](https://info.mobilerobot.com/safety-compliance/safety-overview/emergency-stops-and-manual-takeover/) (https://info.mobilerobot.com/safety-compliance/safety-overview/emergency-stops-and-manual-takeover/) or the belly button (stop and reverse);
- the [tiller-position switches](https://info.mobilerobot.com/safety-compliance/safety-functions/tiller-detection/) (https://info.mobilerobot.com/safety-compliance/safety-functions/tiller-detection/), provide emergency stop and manual control.

See [Manual and Autonomous Modes](https://info.mobilerobot.com/documentation/getting-started/manual-and-autonomous-modes/) (https://info.mobilerobot.com/documentation/getting-started/manual-and-autonomous-modes/) for the full mode model and [Manual Operation](https://info.mobilerobot.com/documentation/user-guides/manual-operation/) (https://info.mobilerobot.com/documentation/user-guides/manual-operation/), for manual work.